

# Transmission Cooler Line Adapter Hose Application Guide

## GM VEHICLES - SILVER

Vehicle Description	Year	Part # (Male/Female)
GM 5/16" diameter	All	J/J1
GM 3/8" diameter	All	K/K1
GM 7/16" inverted flare	Newer SUV's & trucks	#21/ #22
GM 1/2" inverted flare	Newer SUV's & trucks	#23/#24
GM 3/8" quick connect	1996 or newer	#2 & 3/8" female hose
GM 1/2" quick connect	Newer SUV's & trucks	#25 & 1/2" female hose
GM 5/8" quick connect for pick ups (Allison 1000 series)		#27/#28
GM 3/4" quick connect for pick ups (Allison 2000 series)		#29/#30

## FORD VEHICLES - GOLD

Ford F150	Newer	#9 & 3/8" female hose
Ford 5/16" diameter	1980 & newer	B/B1
Ford 3/8" diameter	1985 & newer	A/A1
Ford quick connect fitting	1985 & newer	#1 & 5/16" female hose
Ford Contour & Mystique	1995 & newer	D/D1
Ford Escort	1995 & newer	G/G1
Ford Diesel Truck		E/E1
Ford Aerostar, Jaguar, Mercedes & Cadillac	1985 & newer	C/C1

## CHRYSLER VEHICLES - GRAY

Jeep Cherokee	1980 to 1986	H/H1
Jeep Cherokee, Grand Cherokee with quick connect fitting	1987 & newer	#3 & 3/8" female hose
Jeep Cherokee, Grand Cherokee	1993 & 1994	I/I1
Jeep Cherokee, Grand Cherokee	1998	V/V1
Jeep Grand Cherokee	1995 & newer	#3 & 3/8" female hose
Jeep Liberty		#61/#62
Dodge Durango		F/F1
Dodge Ram 1500	1999 & newer	CA/CA1
Dodge Truck V6 & V8	1995 & newer	#3 & 3/8" female hose
Dodge Truck V10 & Diesel	1995 & newer	#4 & 1/2" female hose

## BMW/MERCEDES/VOLVO VEHICLES - BLACK

BMW & Mercedes	1985 & newer	M/M1 or Ford (Gold): G/G1
BMW flare adapter	Up to 1985	N/N1
BMW O-Ring adapter	1987 & newer	L/L1
BMW w/quick connect adapter		#37 & 3/8" female hose
Landrover	Newer	#37/#39 & #41/#42
Saab 14 mm fittings		#33/
Volvo, Jaguar, Mercedes	1985 & newer	Ford (Gold): C/C1
Volvo all models	1993 & newer	AV/AV1 & #99, also #31
Volkswagen all models		VO & #35 (total of 4 pcs)

## Most imports and all other types of vehicle optional adapters are:

European Kit: #400100EU

#31, #33/34, #35, #37, #38/39, #41/42, #43/44, #99, #VO

Chrysler Kit: #400100CH - #CA/CA1, #F/F1, #V/V1, #61/62

Ford Kit: #400100FD - #9, #9A, #97/98

\* = Optional adapter/not part of Standard Kit

GM Kit: #400100GM - #20, #21/22, #23/24, #25, #26, #27/28, #29/30

Allison Kit #1: #400100AL1 - #26, #27, #28

Allison Kit #2: #400100AL2 - #29, #30

